


DTMF DECODER USER'S GUIDE



Operation:

1. Insert a 9 Volt Battery into the decoder (battery not included).
2. Press the Power Switch.
3. The decoder will display the model number.
4. Press the clear button.
5. Direct audio tones at the Microphone, or connect a line level audio input.
6. Numbers will display on LCD monitor (maximum of 16 digits)

Trouble Shooting:

1. Make sure audio source is loud and close to speaker input.
2. If audio source is played from a tape player, make sure you use the same tape player that the audio was recorded from. (some tape players record at slow speeds, so playback on a regular tape player may play the audio too fast for decoder).